



# PHASER



- 4-stage analog phase shifter
  - 2 wave LFO
- Current Draw: 15mA (at +12V)  
12mA (at -12V)  
**12HP**



Make sure that you connect the module to the power in the right way.

The red stripe of the ribbon indicates -12V



dreadbox